

Calling UE

Caller User Equipment




IMS Network



IMS 1



IMS 2



IMS 1 MRF



Called UE

Called User Equipment

