



IMS Conference (IMS Conference Call)								
Calling UE	IMS Network							Called UE
Caller User Equipment	IMS 1		IMS 1 MRF		IMS 2			Called User Equipment
Conference Initiator	Initiating P-CSCF	Initiating S-CSCF	MRFC-AS	MRFP	Participating I-CSCF	Participating S-CSCF	Participating P-CSCF	Conference Participant

Initiating an IMS conference using the Conference Factory URI




User inviting another user to a conference by sending a REFER request




Called Conference Participant enters Conference



IMS Conference (IMS Conference Call)								
Calling UE	IMS Network							Called UE
Caller User Equipment	IMS 1		IMS 1 MRF		IMS 2			Called User Equipment
Conference Initiator	Initiating P-CSCF	Initiating S-CSCF	MRFC-AS	MRFP	Participating I-CSCF	Participating S-CSCF	Participating P-CSCF	Conference Participant



Notify Conference Initiator that the user has successfully entered the conference



Conference in progress



Conference Caller leaving the Conference

