



Component Interfaces (GSM Mobile Terminated GSM)						
Cell	Mobile Network					EventStudio System Designer 6
Mobile Station	Base Stations	NSS				
GSM Mobile	BSS	Mobile Switching Center	VLR	HLR	SMS-GMSC	Service Center
						21-Jan-14 16:59 (Page 1)

In this call flow we will look at how a terminating SMS is handled in GSM. Setting up a terminating SMS session is a multi-step process.

- (1) Interrogate the MSC to locate the subscriber
- (2) Setting SMS session setup and acquiring radio resources
- (3) Sending the SMS.
- (4) Releasing the session and associated radio resources.




Component Interfaces (GSM Mobile Terminated GSM)						
Cell	Mobile Network					EventStudio System Designer 6
Mobile Station	Base Stations	NSS				
GSM Mobile	BSS	Mobile Switching Center	VLR	HLR	SMS-GMSC	Service Center
						21-Jan-14 16:59 (Page 2)



Now the MSC VLR needs to locate the subscriber in the location area. Since the location area might spawn several cells, a paging mechanism is used to locate the subscriber. The MSC uses a TMSI (Temporary Mobile Subscriber Identify) to address the mobile phone. The TMSI is used so as to protect the privacy of the called subscriber. Note that, the BSSMAP PAGING message will be sent to all the BSCs that handle the Maryland Location Area.

All cells in the location area will broadcast the Page message on the Paging Channel (PCH). All mobile phones listen to this channel every few seconds. The mobile is located in the Bethesda cell. It receives this page message.

Begin RR Connection Establishment



RR connection establishment is triggered by sending the Channel Request message. This message requests the Base Station System (BSS) for allocation for radio resources for the RR connection setup. The mobile now waits for an assignment on the Access Grant Channel (AGCH). At this point the mobile is listening to the AGCH for a reply.

The BSS transmits the radio resource assignment to the Mobile via the AGCH channel. The message also contains the time and frequency corrections. The time corrections allow the mobile to time it's transmissions so that they reach the BSS only in the specified slot. The frequency corrections correct for the Doppler shift caused by the mobile's motion.

This is the first message that is sent after tuning to the channel. The Mobile initiates a LAPm connection with the BSC by sending a Set Asynchronous Balanced Mode (SABM) message. The service request message meant for the MSC is also sent in this message.


The BSS replies with Unnumbered Acknowledge (UA) to complete the LAPm setup handshake

The BSS receives the RR Page Response message from the mobile and forms a "BSSMAP COMPLETE LAYER 3 INFORMATION". The BSS then piggy backs the message on the SCCP connection request message.


The MSC forwards the request to the VLR.

Component Interfaces (GSM Mobile Terminated GSM)						
Cell	Mobile Network					EventStudio System Designer 6
Mobile Station	Base Stations	NSS				
GSM Mobile	BSS	Mobile Switching Center	VLR	HLR	SMS-GMSC	Service Center
						21-Jan-14 16:59 (Page 3)

LEG: Initiate Authentication Procedure



Enable Ciphering



VLR initiates ciphering.

At this point the VLR responds back to the MSC. This message is a response to the "MAP PROCESS ACCESS REQUEST" that was received earlier.

Finally, VLR acknowledges "MAP SEND INFO FOR MT SMS".


Since the subscriber has been successfully authenticated, the MSC initiates ciphering of the data being sent on the channel. The channel is ciphered so as to protect the call from eavesdropping.

The BSS sends the CIPHERING MODE COMMAND to the mobile. The mobile will be able to receive this message as the transmission from the BSS is still in clear.

Ciphering has already been enabled, so this message is transmitted with ciphering. The BSS will receive this message as it is already expecting ciphered data in the receive direction.

BSS replies back to the MSC, indicating that ciphering has been successfully enabled.


SMS sent from SC to Mobile



The Service Center (SC) now sends the SMS to the GMSC.

The GMSC now sends the SMS to the MSC.

Component Interfaces (GSM Mobile Terminated GSM)						
Cell	Mobile Network					EventStudio System Designer 6
Mobile Station	Base Stations	NSS				
GSM Mobile	BSS	Mobile Switching Center	VLR	HLR	SMS-GMSC	Service Center
						21-Jan-14 16:59 (Page 4)



The BSC initiates a LAPm connection with the Mobile by sending a Set Asynchronous Balanced Mode (SABM) message.

The Mobile replies with Unnumbered Acknowledge (UA) to complete the LAPm setup handshake

The SMS content is being carried in CP-DATA message sent from the MSC to the Mobile. The SMS payload is carried in the RPDU contained in the RPDATA.

On successful transmission over Radio Connection CP-ACK is sent.

The CP-DATA is now acknowledged from the Mobile to the MSC.

Mobile confirms the delivery of the SMS.

This message signals to the GMSC that the SMS has been delivered to the terminating mobile.

The SMS Delivery report is now forwarded to the SC.

Call release has been completed, now the RR connection is released by the MSC.

The BSS initiates RR release with the mobile.

The BSS informs the MSC that the RR connection has been released.

The mobile sends a disconnect message to release the LAPm connection.

Component Interfaces (GSM Mobile Terminated GSM)							
Cell	Mobile Network						EventStudio System Designer 6
Mobile Station	Base Stations	NSS					
GSM Mobile	BSS	Mobile Switching Center	VLR	HLR	SMS-GMSC	Service Center	21-Jan-14 16:59 (Page 5)



The BSS replies with an Unnumbered Acknowledge message.