



Module Interfaces (GSM Location Update Procedure)

Subscribers	GSM Network	EventStudio System Designer 4.0
-------------	-------------	---------------------------------


GSM Mobile reaches cell boundary (both cells in same Location Area)




GSM Mobile reaches Location Area boundary (old and new cells are in different Location Areas)




RR Connection Setup



GSM Location Update Procedure



Enable Ciphering



RR Connection Release

